



Saxophone Repair – Indicative Price List

Last Updated on 3 April 2017

	Play Condition	Standard Service	Overhaul
Soprano	\$30 + parts (*)	\$240 + parts	\$420 + parts
Alto – Student models	\$30 + parts (*)	\$240 + parts	\$420 + parts
Alto – Professional models	\$30 + parts (*)	\$360 + parts	\$720 + parts
Tenor – Student models	\$30 + parts (*)	\$300 + parts	\$510 + parts
Tenor – Professional models	\$30 + parts (*)	\$400 + parts	\$840 + parts
Baritone – Student models	\$30 + parts (*)	\$360 + parts	\$750 + parts
Baritone – Professional models	\$30 + parts (*)	\$480 + parts	\$960 + parts

(*) Minimum charge. 30 minutes labour included. Extra labour charged at \$60/hr in 10 minute increments.

Play Condition: returns the instrument to play condition – these are usually one-off and straightforward repairs, such as the replacement of a single pad, the straightening of a bent key, adjust key height, etc. This service carries a 90 day warranty on new pads. Please note that dent removal will never fall in this category.

Standard Service: recommended every 12 to 18 months. Instrument is disassembled, cleaned and hand polished. Necessary pads, corks, felts and springs replaced. Spring tension adjusted. Key regulation and height adjustment. Keywork lubricated. Instrument leak tested and play tested. This service carries a 90 day warranty on new pads.

Overhaul: generally only needed once or twice in the lifetime of an instrument, and possibly never for school or beginner instruments. This really depends on the age of the instrument and how well it has been maintained over time. Same as a full service plus: all pads, corks and felts replaced, tone holes levelled/refaced, dents removed, all springs replaced. This service carries a 90 day warranty on new pads.

Please note: excessive tone hole/tenon work will incur a surcharge.

Prices subject to change without notice.